

# Upgrade Your Black NEO Series For Free

## These are just some benefits of Upgrading!!!

- Faster Indexing of your stored data
- Quicker response time in setting up more advanced features
  - Quicker Boot response

Step 1: Download the Firmware file from [ftp2.eos.com.au](http://ftp2.eos.com.au)  
Username: videoman Password is – welcome... Go to the Folder BLACK NEO SERIES - Firmware – 200FPS and download the two files named:


iDVR800T8.10.040.61ENCUTAPM.img – 8 Channel NEO WHITE BUTTONS ONLY  
iDVR1600T9.10.045.61ENCUTAPM.img – 16 Channel NEO WHITE BUTTONS ONLY

iDVR400T3.10.88.61ENCUTAPM.img – 4 Channel NEO – In the 100FPS Folder

Step 2: Copy all files to a memory stick and install the Memory stick in your NEO DVR.



Step 3: Click the Menu button and click on System Setup, then go to System Management.



Step 4: Click on the PRESS button next to "F/W Upgrade" then another window will pop up select the "USB Storage" as the device to upgrade your NEO DVR after the upgrade is completed the machine will restart. Congratulations You're Finished.

